



Olympus Pen E-PL7 Battery Replacement

This guide will help you replace the battery in the Olympus Pen E-PL7.

Written By: Kelsea Weber




INTRODUCTION

Camera not turning on? The battery may need to be recharged or replaced. Use this guide to replace the battery and get back to taking awesome photos!

Step 1 — Battery



- Turn the camera upside down.
 - Push the grey tab to the right to open the battery compartment.
 - Pull out the battery.
-  The battery is not shown in these photos.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-08-17 07:55:38 PM.